


Sonos wireless music integration


It is required to use the Alarm.com app on your smartphone (NOT the web site) to control playback on your Sonos speakers.

Requirements


Note: Some music streaming services (e.g., Spotify) require premium memberships to use with Sonos. For more information about which services require a premium membership, refer to the Sonos manufacturer.

- iOS device with firmware version 8.0+
- Android device with firmware version 2.1+
- Alarm.com mobile app version 4.10.4+
- Current versions of the Sonos mobile app & speaker software
- Interactive Gold service package




1. Log into the app.
2. Tap .
3. Tap **Add Device**.
4. Tap **Audio**.
5. Tap **Sonos Wireless Audio Player**.



6. Tap **Begin Installation**.



7. Tap **Continue** to sign in with Sonos.
8. Tap **Continue**.
9. Enter the Sonos account information, then tap **Sign In**.
10. Tap **Okay** to allow Alarm.com to control your Sonos system.
11. Wait while new devices are discovered.
12. The device(s) is now installed. Tap Continue to return to the app.



Missing speaker(s) from the app later, or receive a speaker "malfunction"?
Open the app, select audio, click on gear in upper right, then swipe down to reconnect missing speakers.